



**Above**  
Section

**Left**  
Section detail: the truss web diagonals densify as the shear force increases along the section, and trusses taper as the bending forces reduce towards the cantilever tip, the ground pin connection and the central node above the spine.